



Multipath Propagation

Scattering at the mobile:

- Local buildings cause reflections
- High Doppler spread due to mobile motion
- small scattering radius – small delay spread

Remote scattering:

- Dominant scatterers cause specular multipath with significant delay and angle spreads
- Time-varying multipath

Scattering at base:

- Local buildings cause reflections
- Worse for low elevation angles
- Severe angle spread giving space-selective fades
- Generally time invariant fading





Typical Channel Characteristics


Environment	Cell type	Delay spread	Angle spread	Doppler spread
Flat rural	Macro	$0.5 \mu\text{s}$	1°	190 Hz
Urban	Macro	$5 \mu\text{s}$	20°	120 Hz
Hilly	Macro	$20 \mu\text{s}$	30°	190 Hz
Dense urban	Micro	$0.3 \mu\text{s}$	120°	10 Hz
Indoor	Pico	$0.1 \mu\text{s}$	360°	5 Hz

Table of typical channel parameters (after Paulraj).




Code Division Multiple Access

(a)



(b)



(a) Generic DS-SS transmitter and
(b) receiver.

